

Brief notes on the installation of corner fridges.

- First check that there is a clearance of at least 3.5/4 cm between the right-hand back wall of the corner fridge and the house wall, to ensure that the unit has sufficient space and adequate ventilation.
- Now make an aperture in the right-hand back wall, 8.5 cm from the ceiling and 10 cm from the left-hand side wall.
- The aperture must have a height of 740 mm and a width of 440 mm.
- Install an air barrier of the long type, as shown in the drawing.
- Install an air grille in the plinth to allow air to enter the unit, and in the case of installation to the full height of the kitchen ceiling, 2 air grilles must be installed above the door of the corner fridge for ventilation.
- Now secure the unit in position with 4 screws.

